



## Tips and techniques:

- Heat DRY iron to a medium or cool setting appropriate for your gown's fabric. (Cooler setting may require a slightly longer pressing time).
- Always use a pressing cloth!
- For larger designs, apply one piece at a time.
- When applying to tulle, use an old cloth underneath (in addition to the pressing cloth on top). Once flock is applied--**and still hot**--gently pull tulle away from the cloth underneath. *Adhesive will stick to this cloth, so use an old cloth that you can throw away.* If flock cools too quickly and tulle sticks to the cloth underneath, simply press flock for a few seconds to reheat and try again.



FA15471 Skull & Crossbones